



Nosecone Pieces
Included in Every Kit

Step #1. Measure Front
(Weld to Weld)

Step #2. Measure Middle
(Weld to Weld)
if applicable

Step #3. Measure Back
(Weld to Weld)